


# FLUE DESIGN & INSTALLATION GUIDE





## FLUE SPECIFICATION FOR EASYPELL 20 KW & 32 KW PELLET BOILERS

# INSTALLATION GUIDE

## RECOMMENDED MINIMUM CLEARANCE DIMENSIONS

**NOTE:** To install the heating system properly and ensure economical operation, you need to make sure that minimum clearance dimensions indicated below are observed when setting up the boiler.

In addition, make sure that New Zealand legislation is complied with relating to the minimum clearance of the flue gas tube.



## PLACEMENT OF RUBBER PLATES

**NOTE:** THE PELLET BOILER MUST BE PLACED ON THE SUPPLIED RUBBER PLATES.